

# ZENIT® Z120 G2

ZENIT Z120 G2 PROFESSIONAL ZOOM PAR IP65



17CH Mode						
Ch.	Function	Values			Sub-Group	
1	Dimmer	000	-	255	0% to 100%	Dimmer
2	Dimmer fine	000	-	255	0% to 100%	
3	Strobe Functions	000	-	005	Strobe open	Multifunctional Strobe
		006	-	010	Strobe closed	
		011	-	033	Pulse Random, slow -> fast	
		034	-	056	Ramp up Random, slow -> fast	
		057	-	079	Ramp down Random, slow -> fast	
		080	-	102	Random Strobe Effect, slow -> fast	
		103	-	127	Strobe Break Effect, 5s.....1s (Short burst with break)	
		128	-	250	Strobe slow -> fast <1Hz - 20Hz	
251	-	255	Strobe open			
4	Red	000	-	255	0% to 100%	Red
5	Red fine	000	-	255	0% to 100%	Green
6	Green	000	-	255	0% to 100%	
7	Green fine	000	-	255	0% to 100%	Blue
8	Blue	000	-	255	0% to 100%	
9	Blue fine	000	-	255	0% to 100%	White
10	White	000	-	255	0% to 100%	
11	White fine	000	-	255	0% to 100%	
12	Colour Macro & Colour Jumping & Colour Fading (overrides RGBW)	000	-	005	Colour off	Colour Macro
		006	-	013	Red	
		014	-	021	Amber	
		022	-	029	Yellow warm	
		030	-	037	Yellow	
		038	-	045	Green	
		046	-	053	Turquoise	
		054	-	061	Cyan	
		062	-	069	Blue	
		070	-	077	Lavender	
		078	-	085	Mauve	
		086	-	093	Magenta	
		094	-	101	Pink	
		102	-	109	Warm White	
		110	-	117	White	
		118	-	125	Cold White	
126	-	127	Colour Jumping Stop			
128	-	191	Colour Jumping Speed slow -> fast / Colour 1 -> 12			
192	-	255	Colour Fading Speed slow -> fast / Colour 1 -> 12			
13	Colour Temperature Correction (affects RGBW and Colour Macros)	000	-	005	off	Colour Temperature Correction
		006	-	255	cold -> warm	

# ZENIT® Z120 G2

ZENIT Z120 G2 PROFESSIONAL ZOOM PAR IP65



14	Zoom	000	-	255	narrow to wide	Zoom
15	Zoom fine	000	-	255	narrow to wide	
16	Set Dimmer Curve	000	-	005	No function	Set Dimmer Curve
		006	-	063	Linear Dimmer Curve	
		064	-	127	Exponential Dimmer Curve	
		128	-	191	Logarithmic Dimmer Curve	
		192	-	255	S-Curve Dimmer Curve	
17	Device Settings (please read remark 1*)	000	-	005	No function	Device Settings
		006	-	027	Dimmer Response LED (Hold 3s)	
		028	-	049	Dimmer Response Halogen (Hold 3s)	
		050	-	093	No function	
		094	-	115	PWM Frequency 800 Hz (Hold 5s)	
		116	-	137	PWM Frequency 1200 Hz (Hold 5s)	
		138	-	159	PWM Frequency 2000 Hz (Hold 5s)	
		160	-	181	PWM Frequency 3600 Hz (Hold 5s)	
		182	-	203	PWM Frequency 12 kHz (Hold 5s)	
		204	-	225	PWM Frequency 25 kHz (Hold 5s)	
		226	-	247	Zoom Reset (Hold 5s)	
248	-	255	No function			

EN: (1\*) After the adjustments have been made, set the value to 000 to avoid disturbance by endless function call.

DE: (1\*) Nachdem die Einstellungen vorgenommen wurden, stellen Sie den Wert auf 000 ein, um Störungen durch endlosen Funktionsaufruf zu vermeiden.

FR: (1\*) Une fois les ajustements effectués, réglez la valeur sur 000 pour éviter les perturbations par appel de fonction sans fin.

ES: (1\*) Después de realizar los ajustes, establezca el valor en 000 para evitar perturbaciones mediante una llamada de función sin fin.

PL: (1\*) Po dokonaniu ustawień ustaw wartość na 000, aby uniknąć zakłóceń przez niekończące się wywołanie funkcji.

IT: (1\*) Dopo aver effettuato le regolazioni, impostare il valore su 000 per evitare disturbi causati da una chiamata a funzione infinita.